



Starter Block Ramp

Part No. PPP-SBR

Position upper steel edge of SBR even with, or slightly below, horizontal approach. Finger-test or use a straight edge to determine SBR height against beveled approach edge.

Carefully seat both SBR mounting screws. Avoid over tightening of fasteners to prevent hole stripping in plastic and wood gutters.



CAUTION; Avoid over tightening of fasteners to prevent hole stripping in plastic and wood gutters.



On some later-made rubber starter blocks (see image above) the thin rubber extension may need to be trimmed or tucked under approach. Poor results may occur from securing SBR onto this thin thread of rubber.